




CLIP-IN NUTS

Helicoidal caged nuts: Type CNS


Recommended use:

These caged nuts are inserted from the front of the substrate simply by pressing on the cage. The nuts can be removed and refitted on another substrate.



| SCREW SIZE | P = PANEL THICKNESS | REFERENCE | M | N | Ø F | e | TIGHTENING TORQUE ** IN Nm (max) |
|------------|---------------------|--------------|------|-----|------|-----|-------------------------------------|
| M5 | 0.7 to 4 | CNS-8995 NJ | 14.5 | 4.3 | 10.3 | 0.5 | 8 |
| M6 | 0.7 to 4 | CNS-8636G NJ | 14.7 | 4.6 | 10.4 | 0.5 | 12 |

** Values obtained in the lab using a power screwdriver (at 400 rpm) on a hardened steel support with class 8.8 and 12.9 screws (non-subcoated and non-zinc plated).



Recommended assembly method:

1. Insert and clip the caged nut in the punched hole.
2. Once in position, the nut is self-retaining.
3. Position the panel to be fastened and engage the screw/bolt in the nut.
4. Tighten the screw/bolt, thereby rotating the nut and tensioning the assembly.